



DESCRIPTION

A-Pager is a compact device similar to a pager but with 2-way radio capabilities and indoor positioning.

A-Pager is developed to integrate with the CMS for Alert4U2 environments, and it is intended to replace separate pager systems in smaller installations.

TECHNICAL DATA

Alarm button / assault alarm

Positioning

Built-in positioning in combination with COBS positioning transmitters (A-POS)

User groups

A flexible solution with several different users Login with user-id and group-id.

Built-in vibrator

For noisy environments or when discretion is required.

Robust durable design

A-Pager has a robust design to handle rough environments.

Broadcast

By sending broadcast messages, you can reach several A-pagers within a few seconds.

Alarms / messages

- Can store 32 messages
- 50 characters per message
- Automatic and manual acknowledgement
- Broadcast messages
- Automatic alarms

Physical data

- Size: (LxWxH) 100x48x21mm
- Weight: 60g (incl. battery)
- Display: Color display 128x128px,
- 65,000 colours
- Temperature: 5 °C to 55 °C
- Standby: approx. 200 hours
- Battery: Rechargeable Li-Po, 600mA
- Vibrator

Accessories:

- Desktop charger
- Leather pouch

Tillbehör:






- Laddfack
- Läderväska

Standarder

- EN 60950-1
- (2006+A1+A2+A11+A12:2011)
- EN 301 489-1 v.2.1.1
- EN 301 489-3 v.1.6.1
- EN 300220-1 v.3.1.1
- EN 300220-2 v.3.1.1
- EN 300220-3-1 v.2.1.1

Conformity

- 2014/53 EU (RED)
- 2014/35 EU (LVD)
- 2014/30 EU (EMC)
- 2011/65 EU (RoHS2)

Part No.	Description	
9009742	<p>A-Pager kit</p> <p>The kit includes: 1pc A-Pager, 1pc A-Pager Mini-USB Adaptor (9009750), 1pc USB A - Mini-USB cable, 1pc USB AC/DC adaptor 1000mA.</p>	
9009743	<p>Desktop charger for A-Pager (Optional accessory)</p> <p>The kit includes: 1pc deskstand, 1pc cable for power connection between two deskstands, 1pc adapter to connect to deskstands.</p> <p>Note: AC/DC Adaptor (9009763) for multiple desktop chargers is sold separately.</p>	
9009744	Leather pouch A-Pager (Optional accessory)	
9009749	Battery for A-Pager (Sparepart)	
9009750	<p>A-Pager Mini-USB Adaptor (Sparepart)</p> <p>Connect the AC adapter with the Mini USB adapter. Place the Mini-USB adapter into the contacts on the bottom of the unit until it clicks into the keyboard side</p>	
9009763	<p>AC/DC adaptor for A-Pager multi charger (Accessory)</p> <p>One AC/DC adaptor supports up to four slots.</p> <ul style="list-style-type: none"> Output: 5V 3000mA. 	